

## Locking Procedure

1. Place the items you wish to store inside the unit and close the door.

8 8 8 8 8 + CLEAR


2. Enter a 4- to 6-digit PIN of your choice.

4- to 6-digit PIN

3. Press **CLOSE** key to lock.

4. Once locking is complete,  
the LED display will show **CLOSED**

\* If you need to interrupt the PIN entry process and start over,  
press **CLEAR** key.




## Unlocking Procedure

Enter the PIN when locking

1. When you enter the PIN code confirmed during locking,  
the door will unlock automatically.

2. Once unlocking is complete,  
the LED display will show **OPENED**



## Security Block

If you enter an invalid PIN three times in a row, the security lock will automatically activate for approximately 15 minutes.

- When an invalid PIN is entered, the LED display will show **E-CODE**.
- After entering an invalid PIN three times in a row, pressing any key will cause the LED display to show **HOLD 15** and trigger the security lock.

\*The security block will be automatically lifted in approximately 15 minutes.